

1	99	Logical Zone 99
1	100	Cabinet Tamper
1	101	Internal siren tamper
1	102	External siren tamper
1	103	AC fail
1	104	Low battery
1	105	LAN fuse tamper
1	106	Detector fuse tamper
1	107	Low Volts
1	108	PS Fail
1	109	Battery Test
1	110	LAN Comms
1	111	DBus Changed
1	112	Reset
1	113	Phone Line
1	114	Unibus
1	115	Time Report
1	116	Unsecured
1	117	Spare
1	118	Spare
1	119	Spare
1	120	Spare
1	122	Spare
1	123	Spare
1	124	Spare
1	125	Spare
1	126	Spare
1	127	Spare
1	128	Spare
1	129	Spare
1	131	Spare
1	132	Spare
1	133	Door1 Fault
1	134	Door2 Fault
1	135	Door3 Fault
1	136	Door4 Fault
1	137	Door5 Fault
1	138	Door6 Fault
1	139	Door7 Fault
1	140	Door8 Fault
1	141	Door1 Forced
1	142	Door2 Forced
1	143	Door3 Forced
1	144	Door4 Forced
1	145	Door5 Forced
1	146	Door6 Forced
1	147	Door7 Forced

1	148	Door8 Forced
1	149	Door1 DOTL
1	150	Door2 DOTL
1	151	Door3 DOTL
1	152	Door4 DOTL
1	153	Door5 DOTL
1	154	Door6 DOTL
1	155	Door7 DOTL
1	156	Door8 DOTL
1	157	Rdr1 Invalid
1	158	Rdr2 Invalid
1	159	Rdr3 Invalid
1	160	Rdr4 Invalid
1	161	Rdr5 Invalid
1	162	Rdr6 Invalid
1	163	Rdr7 Invalid
1	164	Rdr8 Invalid
1	165	Rdr9 Invalid
1	166	Rdr10 Invalid
1	167	Rdr11 Invalid
1	168	Rdr12 Invalid
1	169	Rdr13 Invalid
1	170	Rdr14 Invalid
1	171	Rdr15 Invalid
1	172	Rdr16 Invalid
1	173	Rdr1 Duress
1	174	Rdr2 Duress
1	175	Rdr3 Duress
1	176	Rdr4 Duress
1	177	Rdr5 Duress
1	178	Rdr6 Duress
1	179	Rdr7 Duress
1	180	Rdr8 Duress
1	181	Rdr9 Duress
1	182	Rdr10 Duress
1	183	Rdr11 Duress
1	184	Rdr12 Duress
1	185	Rdr13 Duress
1	186	Rdr14 Duress
1	187	Rdr15 Duress
1	188	Rdr16 Duress
1	189	Rdr1 Fault
1	190	Rdr2 Fault
1	191	Rdr3 Fault
1	192	Rdr4 Fault
1	193	Rdr5 Fault
1	194	Rdr6 Fault

1	195	Rdr7 Fault
1	196	Rdr8 Fault
1	197	Rdr9 Fault
1	198	Rdr10 Fault
1	199	Rdr11 Fault
1	200	Rdr12 Fault
1	201	Rdr13 Fault
1	202	Rdr14 Fault
1	203	Rdr15 Fault
1	204	Rdr16 Fault
1	205	Ext AC Fail
1	206	Ext Low Battery
1	207	Ext LAN Fuse
1	208	Ext DET Fuse
1	209	Ext Low Volts
1	210	Ext PS Fail
1	211	Ext Battery Test
1	212	C01 Spare
1	213	C01 Spare
1	214	C01 Spare
1	215	C01 Spare
1	216	C01 Spare
1	217	C01 Spare
1	218	C01 Spare
1	219	C01 Spare
1	220	C01 Spare
1	221	C01 Spare
1	222	C01 Spare
257	1	Zone 1
257	2	Zone 2
257	3	Cabinet tamper.
257	4	Panic.
257	5	Door forced.
257	6	Door open too long.
257	7	Operator duress.
257	8	Deadman
257	9	Too many PIN code tries
257	10	LAN Comms Fail
258	3	Cabinet tamper.
258	4	Panic.
258	5	Door forced.
258	6	Door open too long.
258	7	Operator duress.
258	8	Deadman
258	9	Too many PIN code tries
258	10	LAN Comms Fail
513	3	Cabinet tamper.

513	4	Panic.
513	5	Door forced.
513	6	Door open too long.
513	7	Operator duress.
513	8	Deadman
513	9	Too many PIN code tries
513	10	LAN Comms Fail
514	3	Cabinet tamper.
514	4	Panic.
514	5	Door forced.
514	6	Door open too long.
514	7	Operator duress.
514	8	Deadman
514	9	Too many PIN code tries
514	10	LAN Comms Fail
769	33	Cabinet tamper.
769	34	Internal siren tamper.
769	35	External siren tamper.
769	36	AC fail.
769	37	Low battery.
769	38	LAN fuse.
769	39	Detector fuse.
769	40	LAN Comms Fail
769	41	Battery test
769	42	Spare
770	33	Cabinet tamper.
770	34	Internal siren tamper.
770	35	External siren tamper.
770	36	AC fail.
770	37	Low battery.
770	38	LAN fuse.
770	39	Detector fuse.
770	40	LAN Comms Fail
770	41	Battery test
770	42	Spare
1025	1	Door Reed. 1st Door
1025	2	REN. 1st Door
1025	3	REX. 1st Door
1025	4	REN. 2nd Door
1025	5	Door Reed. 2nd Door
1025	6	Tongue Sense. 1st Door
1025	7	Tongue Sense. 2nd Door
1025	8	REX. 2nd Door
1025	9	Cabinet tamper
1025	10	Low volts.
1025	11	Door #1 forced.
1025	12	Door #1 open too long.

1025	13	Door #2 forced.
1025	14	Door #2 open too long.
1025	15	Illegal Card
1025	16	LAN Comms Fail
1026	1	Door Reed. 1st Door
1026	2	REN. 1st Door
1026	3	REX. 1st Door
1026	4	REN. 2nd Door
1026	5	Door Reed. 2nd Door
1026	6	Tongue Sense. 1st Door
1026	7	Tongue Sense. 2nd Door
1026	8	REX. 2nd Door
1026	9	Cabinet tamper
1026	10	Low volts.
1026	11	Door #1 forced.
1026	12	Door #1 open too long.
1026	13	Door #2 forced.
1026	14	Door #2 open too long.
1026	15	Illegal Card
1026	16	LAN Comms Fail
1281	17	Poll Timeout
1281	18	Low Battery
1282	17	Poll Timeout
1282	18	Low Battery
1537	9	Low Volts/Battery
1537	10	Zone 1 Extra
1537	11	Zone 2 Extra
1537	12	Zone 3 Extra
1537	13	Zone 4 Extra
1537	14	Zone 5 Extra
1537	15	Zone 6 Extra
1537	16	Zone 7 Extra
1537	17	LAN Comms Fail
1538	9	Low Volts/Battery
1538	10	Zone 1 Extra
1538	11	Zone 2 Extra
1538	12	Zone 3 Extra
1538	13	Zone 4 Extra
1538	14	Zone 5 Extra
1538	15	Zone 6 Extra
1538	16	Zone 7 Extra
1538	17	LAN Comms Fail
1793	17	Cabinet tamper.
1793	18	Internal siren tamper.
1793	19	External siren tamper.
1793	20	AC fail.
1793	21	Low battery.

1793	22	LAN fuse.
1793	23	Detector fuse.
1793	24	LAN Comms Fail
1793	25	Battery test
1793	26	Spare
1794	17	Cabinet tamper.
1794	18	Internal siren tamper.
1794	19	External siren tamper.
1794	20	AC fail.
1794	21	Low battery.
1794	22	LAN fuse.
1794	23	Detector fuse.
1794	24	LAN Comms Fail
1794	25	Battery test
1794	26	Spare
2049	9	Reed Input. 1st Door
2049	10	Reed Input. 2nd Door
2049	11	Reed Input. 3rd Door
2049	12	Reed Input. 4th Door
2049	13	Tongue Sense Input. 1st Door
2049	14	Tongue Sense Input. 2nd Door
2049	15	Tongue Sense Input. 3rd Door
2049	16	Tongue Sense Input. 4th Door
2049	17	Lock Tamper. 1st Door
2049	18	Lock Tamper. 2nd Door
2049	19	Lock Tamper. 3rd Door
2049	20	Lock Tamper. 4th Door
2049	21	Door Forced. 1st Door
2049	22	Door Forced. 2nd Door
2049	23	Door Forced. 3rd Door
2049	24	Door Forced. 4th Door
2049	25	Door Open Too Long (DOTL). 1st Door
2049	26	Door Open Too Long (DOTL). 2nd Door
2049	27	Door Open Too Long (DOTL). 3rd Door
2049	28	Door Open Too Long (DOTL). 4th Door
2049	29	Invalid Card (in or out). 1st Door
2049	30	Invalid Card (in or out). 2nd Door
2049	31	Invalid Card (in or out). 3rd Door
2049	32	Invalid Card (in or out). 4th Door
2049	33	Cabinet Tamper
2049	34	General Lock Fault.
2049	35	Battery Test Fail
2049	36	AC Fail
2049	37	Low Battery
2049	38	LAN FUSE
2049	39	Detector FUSE
2049	40	LAN Comms Fail

2050	9	Reed Input. 1st Door
2050	10	Reed Input. 2nd Door
2050	11	Reed Input. 3rd Door
2050	12	Reed Input. 4th Door
2050	13	Tongue Sense Input. 1st Door
2050	14	Tongue Sense Input. 2nd Door
2050	15	Tongue Sense Input. 3rd Door
2050	16	Tongue Sense Input. 4th Door
2050	17	Lock Tamper. 1st Door
2050	18	Lock Tamper. 2nd Door
2050	19	Lock Tamper. 3rd Door
2050	20	Lock Tamper. 4th Door
2050	21	Door Forced. 1st Door
2050	22	Door Forced. 2nd Door
2050	23	Door Forced. 3rd Door
2050	24	Door Forced. 4th Door
2050	25	Door Open Too Long (DOTL). 1st Door
2050	26	Door Open Too Long (DOTL). 2nd Door
2050	27	Door Open Too Long (DOTL). 3rd Door
2050	28	Door Open Too Long (DOTL). 4th Door
2050	29	Invalid Card (in or out). 1st Door
2050	30	Invalid Card (in or out). 2nd Door
2050	31	Invalid Card (in or out). 3rd Door
2050	32	Invalid Card (in or out). 4th Door
2050	33	Cabinet Tamper
2050	34	General Lock Fault.
2050	35	Battery Test Fail
2050	36	AC Fail
2050	37	Low Battery
2050	38	LAN FUSE
2050	39	Detector FUSE
2050	40	LAN Comms Fail
2305	7	Cabinet Tamper
2305	8	Low Volts
2305	9	LAN Comms Fail
2306	7	Cabinet Tamper
2306	8	Low Volts
2306	9	LAN Comms Fail
2817	1	Zone 1
2817	2	Zone 2
2817	3	Cabinet Tamper
2817	4	AC Fail (Mains Failure)
2817	5	Low Battery
2817	6	Battery Fail
2817	7	Detector Fuse Fail
2817	8	LAN Fuse Fail
2817	9	Battery Fuse Fail

2817	10	Auxiliary 2 Fuse Fail
2817	11	Auxiliary 2 Tamper
2817	12	Detector Over Current
2817	13	Battery Over Current
2817	14	Over Volts
2817	15	Under Volts
2817	16	Slave Failure
2817	17	Battery Test Fail
2817	18	LAN Comms Fail
2818	3	Cabinet Tamper
2818	4	AC Fail (Mains Failure)
2818	5	Low Battery
2818	6	Battery Fail
2818	7	Detector Fuse Fail
2818	8	LAN Fuse Fail
2818	9	Battery Fuse Fail
2818	10	Auxiliary 2 Fuse Fail
2818	11	Auxiliary 2 Tamper
2818	12	Detector Over Current
2818	13	Battery Over Current
2818	14	Over Volts
2818	15	Under Volts
2818	16	Slave Failure
2818	17	Battery Test Fail
2818	18	LAN Comms Fail
3073	33	Cabinet tamper.
3073	34	Low Volts
3073	35	RF Transmitter Low Battery
3073	36	RF Transmitter Poll Fail
3073	37	RF Transmitter Jam
3073	38	LAN Comms Fail
3074	33	Cabinet tamper.
3074	34	Low Volts
3074	35	RF Transmitter Low Battery
3074	36	RF Transmitter Poll Fail
3074	37	RF Transmitter Jam
3074	38	LAN Comms Fail
4097	1	Zone 1
4097	2	Zone 2
4097	3	Door Reed
4097	4	Door Tongue
4097	5	Door Lock Tamper
4097	6	Door Forced
4097	7	Door DOTL
4097	8	Cabinet
4097	9	AC Fail
4097	10	Low Battery

4097	11	LAN Fuse
4097	12	Detector Fuse
4097	13	Low Voltage on LAN+ or DET+
4097	14	Power supply failure
4097	15	Battery test
4097	16	Illegal Card
4097	17	Duress
4097	18	Rdr Tamper
4097	19	Panic
4097	20	Pin Attempts
4097	21	Temperature
4097	22	Light Level
4097	23	LAN Comms
4353	1	Zone 1
4353	32	Zone 32
4353	33	Cabinet Tamper
4353	34	Internal siren tamper
4353	35	External siren tamper
4353	36	AC fail
4353	37	Low battery
4353	38	LAN fuse
4353	39	Detector fuse
4353	40	Low Voltage on LAN+ or DET+
4353	41	Power supply failure
4353	42	Battery test
4353	43	AC fail (External Power supply)
4353	44	Low battery (External Power supply)
4353	45	LAN fuse (External Power supply)
4353	46	Detector fuse (External Power supply)
4353	47	Low Voltage (External Power supply)
4353	48	Power supply fail(External Power supply)
4353	49	Battery test (External Power supply)
4353	50	Unibus
4353	51	LAN Comms
4609	1	Zone 1
4609	8	Zone 8
4609	9	Door 1 Reed
4609	10	Door 2 Reed
4609	11	Door 1 Tongue
4609	12	Door 2 Tongue
4609	13	Door 1 Tamper
4609	14	Door 2 Tamper
4609	15	Door 1 Forced
4609	16	Door 2 Forced
4609	17	Door 1 DOTL
4609	18	Door 2 DOTL
4609	19	Cabinet

4609	20	AC fail
4609	21	Low Battery
4609	22	LAN Fuse
4609	23	Detector Fuse
4609	24	Low Voltage on LAN+ or DET+
4609	25	Power supply fail
4609	26	Battery Test
4609	27	Rdr1 Invalid card
4609	28	Rdr2 Invalid card
4609	29	Rdr1 Duress
4609	30	Rdr2 Duress
4609	31	Rdr1 Tamper
4609	32	Rdr2 Tamper
4609	33	LAN Comms
4609	34	Unibus
4865	1	Zone 1
4865	8	Zone 8
4865	9	Cabinet tamper
4865	10	AC fail
4865	11	Low battery
4865	12	LAN fuse
4865	13	Detector fuse
4865	14	Low Voltage on LAN+ or DET+
4865	15	Power supply fail
4865	16	Battery test
4865	17	Unibus
4865	18	Download Problem
4865	19	Spare1
4865	20	Lan Comms
4865	21	Door #1 Reed
4865	22	Door #2 Reed
4865	23	Door #3 Reed
4865	24	Door #4 Reed
4865	25	Door #5 Reed
4865	26	Door #6 Reed
4865	27	Door #7 Reed
4865	28	Door #8 Reed
4865	29	Door #1 Tongue
4865	30	Door #2 Tongue
4865	31	Door #3 Tongue
4865	32	Door #4 Tongue
4865	33	Door #5 Tongue
4865	34	Door #6 Tongue
4865	35	Door #7 Tongue
4865	36	Door #8 Tongue
4865	37	Door #1 Tamper
4865	38	Door #2 Tamper

4865	39	Door #3 Tamper
4865	40	Door #4 Tamper
4865	41	Door #5 Tamper
4865	42	Door #6 Tamper
4865	43	Door #7 Tamper
4865	44	Door #8 Tamper
4865	45	Door #1 Forced
4865	46	Door #2 Forced
4865	47	Door #3 Forced
4865	48	Door #4 Forced
4865	49	Door #5 Forced
4865	50	Door #6 Forced
4865	51	Door #7 Forced
4865	52	Door #8 Forced
4865	53	Door #1 DOTL
4865	54	Door #2 DOTL
4865	55	Door #3 DOTL
4865	56	Door #4 DOTL
4865	57	Door #5 DOTL
4865	58	Door #6 DOTL
4865	59	Door #7 DOTL
4865	60	Door #8 DOTL
4865	61	Rdr #1 Invalid
4865	62	Rdr #2 Invalid
4865	63	Rdr #3 Invalid
4865	64	Rdr #4 Invalid
4865	65	Rdr #5 Invalid
4865	66	Rdr #6 Invalid
4865	67	Rdr #7 Invalid
4865	68	Rdr #8 Invalid
4865	69	Rdr #9 Invalid
4865	70	Rdr #10 Invalid
4865	71	Rdr #11 Invalid
4865	72	Rdr #12 Invalid
4865	73	Rdr #13 Invalid
4865	74	Rdr #14 Invalid
4865	75	Rdr #15 Invalid
4865	76	Rdr #16 Invalid
4865	77	Rdr #1 Duress
4865	78	Rdr #2 Duress
4865	79	Rdr #3 Duress
4865	80	Rdr #4 Duress
4865	81	Rdr #5 Duress
4865	82	Rdr #6 Duress
4865	83	Rdr #7 Duress
4865	84	Rdr #8 Duress
4865	85	Rdr #9 Duress

4865	86	Rdr #10 Duress
4865	87	Rdr #11 Duress
4865	88	Rdr #12 Duress
4865	89	Rdr #13 Duress
4865	90	Rdr #14 Duress
4865	91	Rdr #15 Duress
4865	92	Rdr #16 Duress
4865	93	Rdr #1 Tamper
4865	94	Rdr #2 Tamper
4865	95	Rdr #3 Tamper
4865	96	Rdr #4 Tamper
4865	97	Rdr #5 Tamper
4865	98	Rdr #6 Tamper
4865	99	Rdr #7 Tamper
4865	100	Rdr #8 Tamper
4865	101	Rdr #9 Tamper
4865	102	Rdr #10 Tamper
4865	103	Rdr #11 Tamper
4865	104	Rdr #12 Tamper
4865	105	Rdr #13 Tamper
4865	106	Rdr #14 Tamper
4865	107	Rdr #15 Tamper
4865	108	Rdr #16 Tamper
4865	109	AC fail (External Power Supply)
4865	110	Low battery (External Power Supply)
4865	111	LAN fuse (External Power Supply)
4865	112	Detector fuse (External Power Supply)
4865	113	Low Voltage on LAN+ or DET+
4865	114	Power supply fail (External Power Supply)
4865	115	Battery test (External Power Supply)
4865	116	Door #1 Rex
4865	117	Door #2 Rex
4865	118	Door #3 Rex
4865	119	Door #4 Rex
4865	120	Door #5 Rex
4865	121	Door #6 Rex
4865	122	Door #7 Rex
4865	123	Door #8 Rex
4865	124	Door #1 Ren
4865	125	Door #2 Ren
4865	126	Door #3 Ren
4865	127	Door #4 Ren
4865	128	Door #5 Ren
4865	129	Door #6 Ren
4865	130	Door #7 Ren
4865	131	Door #8 Ren
5121	1	Zone 1

5121	32	Zone 32
5121	33	Transmitter Low battery
5121	34	Transmitter Poll Fail
5121	35	Transmitter Jam
5121	36	Cabinet tamper
5121	37	AC fail
5121	38	Low battery
5121	39	LAN fuse
5121	40	Detector fuse
5121	41	Low Voltage on LAN+ or DET+
5121	42	Power supply fail
5121	43	Battery test
5121	44	LAN Comms status
7425	1	Zone 1
7425	32	Zone 32
7681	1	Loss of Polling
7681	2	Message Quarantined
7681	3	Alarm out of Sequence
7681	4	Panel Un-enrolled
7681	5	Panel serial number has changed
7681	6	Invalid message format – ContactID
7681	7	Invalid message format - IRFast
7681	8	Installer access timer has started
7681	9	Installer access timer has stopped
7681	10	Ethernet path warning
7681	11	GPRS 1 path warning
7681	12	GPRS 2 path warning
7681	13	PSTN path warning
7681	14	Repeated loss of polling
7681	15	Alternate path warning
7681	16	Repeated Ethernet Path Warning
7681	17	Repeated GPRS 1 Path Warning
7681	18	Repeated GPRS 2 Path Warning
7681	19	Repeated Dialup ISP Path Warning
7681	21	STU changed path to Ethernet
7681	22	STU changed path to GPRS 1
7681	23	STU changed path to GPRS 2
7681	24	STU changed path to Dial-up ISP
7681	25	STU Service Required
7681	27	Dial-up ISP path warning
7682	1	Loss of Polling
7682	2	Message Quarantined
7682	3	Alarm out of Sequence
7682	4	Panel Un-enrolled
7682	5	Panel serial number has changed
7682	6	Invalid message format – ContactID
7682	7	Invalid message format - IRFast

7682	8	Installer access timer has started
7682	9	Installer access timer has stopped
7682	10	Ethernet path warning
7682	11	GPRS 1 path warning
7682	12	GPRS 2 path warning
7682	13	PSTN path warning
7682	14	Repeated loss of polling
7682	15	Alternate path warning
7682	16	Repeated Ethernet Path Warning
7682	17	Repeated GPRS 1 Path Warning
7682	18	Repeated GPRS 2 Path Warning
7682	19	Repeated Dialup ISP Path Warning
7682	21	STU changed path to Ethernet
7682	22	STU changed path to GPRS 1
7682	23	STU changed path to GPRS 2
7682	24	STU changed path to Dial-up ISP
7682	25	STU Service Required
7682	27	Dial-up ISP path warning
7937	1	Reset
7937	2	Programming Change
7937	3	Panic
7937	4	Low Battery
7937	5	Battery Test
7937	6	Power
7937	7	Test
7937	8	Lost alarms
7937	9	Armed
7937	10	Panel Fail
7937	11	RF Hardware
7937	12	RF Registration
7937	13	RF Low Signal Strength
7937	14	RF Problems
7937	15	GPRS Registration
7937	16	PSTN Line Volts Low
7937	17	PSTN Link
7937	18	PSTN Problems
7937	19	Network Hardware
7937	20	Network Online
7937	21	Network Problems
7937	22	External Hardware
7937	23	Alarm Panel Serial Connection Problems
7937	24	Alarm Panel Serial Connection Failed
7937	25	Alarm Panel Substitution Alarm
7937	48	Cabinet Tamper
7938	1	Reset
7938	2	Programming Change
7938	3	Panic

7938	4	Low Battery
7938	5	Battery Test
7938	6	Power
7938	7	Test
7938	8	Lost alarms
7938	9	Armed
7938	10	Panel Fail
7938	11	RF Hardware
7938	12	RF Registration
7938	13	RF Low Signal Strength
7938	14	RF Problems
7938	15	GPRS Registration
7938	16	PSTN Line Volts Low
7938	17	PSTN Link
7938	18	PSTN Problems
7938	19	Network Hardware
7938	20	Network Online
7938	21	Network Problems
7938	22	External Hardware
7938	23	Alarm Panel Serial Connection Problems
7938	24	Alarm Panel Serial Connection Failed
7938	25	Alarm Panel Substitution Alarm
7938	48	Cabinet Tamper

Users

User No	Name	Call Order	Phone Num.	Mobile Num.	Pager Num.
---------	------	------------	------------	-------------	------------

Types

Type No	Name	Instructions
65025		
65250		
65056	ACTIVATION COMMENT	
65059	ACTIVATION COMPLETED	
101	Alarm	
30981	Alarm Alarm out of Sequence	
30993	Alarm Alternate path warning	
31005	Alarm Dial-up ISP path warning	
30988	Alarm Ethernet path warning	
30989	Alarm GPRS 1 path warning	
30990	Alarm GPRS 2 path warning	
30986	Alarm Installer access timer has started	

30987	Alarm Installer access timer has stopped	
30984	Alarm Invalid message format - ContactID	
30985	Alarm Invalid message format - IRFast	
30979	Alarm Loss of Polling	
30980	Alarm Message Quarantined	
65028	ALARM NO RESTORAL RECEIVED	
32026	Alarm Panel Serial Connection Failed Ala	
32538	Alarm Panel Serial Connection Failed Iso	
31770	Alarm Panel Serial Connection Failed Res	
32282	Alarm Panel Serial Connection Failed Tam	
32025	Alarm Panel Serial Connection Problems A	
32537	Alarm Panel Serial Connection Problems I	
31769	Alarm Panel Serial Connection Problems R	
32281	Alarm Panel Serial Connection Problems T	
30983	Alarm Panel serial number has changed	
32027	Alarm Panel Substitution Alarm Alarm	
32539	Alarm Panel Substitution Alarm Isolate	
31771	Alarm Panel Substitution Alarm Restore	
32283	Alarm Panel Substitution Alarm Tamper	
30982	Alarm Panel Unenrolled	
65092	ALARM PRIORITY INCREASE	
30991	Alarm PSTN path warning	
30994	Alarm Repeated Ethernet Path Warning	
30995	Alarm Repeated GPRS 1 Path Warning	
30996	Alarm Repeated GPRS 2 Path Warning	
30992	Alarm Repeated loss of polling	
201	Alarm Restore	
31002	Alarm STU changed path to Dial-up ISP	
30999	Alarm STU Changed path to Ethernet	

31000	Alarm STU changed path to GPRS 1	
31001	Alarm STU changed path to GPRS 2	
31003	Alarm STU Service Required	
65068	ARCHIVE CLEAN FAIL	
65067	ARCHIVE CLEAN SUCCESS	
65066	ARCHIVE LOG FAIL	
65065	ARCHIVE LOG SUCCESS	
32011	Armed Alarm	
32523	Armed Isolate	
31755	Armed Restore	
32267	Armed Tamper	
65031	BAD CALLER ID	
65029	BAD CHECKSUM IN SIGNAL	
65032	BAD UNRECOGNISED DATA	
32007	Battery Test Alarm	
32519	Battery Test Isolate	
31751	Battery Test Restore	
32263	Battery Test Tamper	
65012	CALLER ID LOGGED	
65001	CLIENT LATE TO CLOSE	
65007	CLIENT UNSET OUT OF HOURS	
1	Close	
65052	CLOSE DURING HOURS	
65030	COMM PORT ERROR	
65024	COMMENT -	
111	Crypt Fail	
211	Crypt Fail Restore	
65072	DATA BACKUP FAIL	
65071	DATA BACKUP SUCCESS	
65053	EMAIL ERROR	
65006	EMAIL FAILURE	
32024	External Hardware Alarm	
32536	External Hardware Isolate	
31768	External Hardware Restore	
32280	External Hardware Tamper	
104	Fault	
204	Fault Restore	
32017	GPRS Registration Alarm	

32529	GPRS Registration Isolate	
31761	GPRS Registration Restore	
32273	GPRS Registration Tamper	
65102	GSM ERROR	
65009	IRFAST DESCRIPT LOGGED WITHOUT DETAILS	
65022	IRFAST NO DESCRIPTION LOGGED	
116	Isolate	
216	Isolate Restore	
65051	LATE TO OPEN	
32010	Lost alarms Alarm	
32522	Lost alarms Isolate	
31754	Lost alarms Restore	
32266	Lost alarms Tamper	
110	Low Battery	
32006	Low Battery Alarm	
32518	Low Battery Isolate	
31750	Low Battery Restore	
210	Low Battery Restore	
32262	Low Battery Tamper	
65005	MANUAL PAGING SIGNAL	
102	Mask	
202	Mask Restore	
32021	Network Hardware Alarm	
32533	Network Hardware Isolate	
31765	Network Hardware Restore	
32277	Network Hardware Tamper	
32022	Network Online Alarm	
32534	Network Online Isolate	
31766	Network Online Restore	
32278	Network Online Tamper	
32023	Network Problems Alarm	
32535	Network Problems Isolate	
31767	Network Problems Restore	
32279	Network Problems Tamper	
65002	NO SIGNALS RECEIVED FROM CLIENT	
65251	NULL	
65084	NULL	

2	Open	
103	Orient	
203	Orient Restore	
32012	Panel Fail Alarm	
32524	Panel Fail Isolate	
31756	Panel Fail Restore	
32268	Panel Fail Tamper	
32005	Panic Alarm	
32517	Panic Isolate	
31749	Panic Restore	
32261	Panic Tamper	
112	Poll Fail	
212	Poll Restore	
65054	POLL SIGNAL	
65021	POLLING FAILURE	
65020	POLLING RESTORE	
32008	Power Alarm	
32520	Power Isolate	
31752	Power Restore	
32264	Power Tamper	
32004	Programming Change Alarm	
32516	Programming Change Isolate	
31748	Programming Change Restore	
32260	Programming Change Tamper	
32018	PSTN Line Volts Low Alarm	
32530	PSTN Line Volts Low Isolate	
31762	PSTN Line Volts Low Restore	
32274	PSTN Line Volts Low Tamper	
32019	PSTN Link Alarm	
32531	PSTN Link Isolate	
31763	PSTN Link Restore	
32275	PSTN Link Tamper	
32020	PSTN Problems Alarm	
32532	PSTN Problems Isolate	
31764	PSTN Problems Restore	
32276	PSTN Problems Tamper	
105	Range	
205	Range Restore	
65055	RECEIVER ERROR MESSAGE	
65000	RECEIVER IN ERROR HAS RESTORED	
65080	RECIEVED SMS	

65003	RECIEVER FAILURE	
65060	REPORT START/END	
32003	Reset Alarm	
32515	Reset Isolate	
31747	Reset Restore	
32259	Reset Tamper	
30725	Restore Alarm out of Sequence	
30737	Restore Alternate path warning	
30749	Restore Dial-up ISP path warning	
30732	Restore Ethernet path warning	
30733	Restore GPRS 1 path warning	
30734	Restore GPRS 2 path warning	
30730	Restore Installer access timer has start	
30731	Restore Installer access timer has stopp	
30728	Restore Invalid message format - Contact	
30729	Restore Invalid message format - IRFast	
30723	Restore Loss of Polling	
30724	Restore Message Quarantined	
30727	Restore Panel serial number has changed	
30726	Restore Panel Unenrolled	
30735	Restore PSTN path warning	
30741	Restore Repeated Dialup ISP Path Warning	
30997	Restore Repeated Dialup ISP Path Warning	
30738	Restore Repeated Ethernet Path Warning	
30739	Restore Repeated GPRS 1 Path Warning	
30740	Restore Repeated GPRS 2 Path Warning	
30736	Restore Repeated loss of polling	
30746	Restore STU changed path to Dial-up ISP	
30743	Restore STU Changed path to Ethernet	
30744	Restore STU changed path to GPRS 1	
30745	Restore STU changed path to GPRS 2	

30747	Restore STU Service Required	
32013	RF Hardware Alarm	
32525	RF Hardware Isolate	
31757	RF Hardware Restore	
32269	RF Hardware Tamper	
32015	RF Low Signal Strength Alarm	
32527	RF Low Signal Strength Isolate	
31759	RF Low Signal Strength Restore	
32271	RF Low Signal Strength Tamper	
32016	RF Problems Alarm	
32528	RF Problems Isolate	
31760	RF Problems Restore	
32272	RF Problems Tamper	
32014	RF Registration Alarm	
32526	RF Registration Isolate	
31758	RF Registration Restore	
32270	RF Registration	
65090	RUNAWAY ALARM	
65088	SILENT REMINDER	
65087	SLEEPING ALARM REMINDER	
65023	SLEEPING ALARM REMINDER	
115	Soak Fail	
215	Soak Restore	
114	Soaking	
214	Soaking Restore	
113	State 12	
213	State 12 Restore	
65027	SUCCESSFUL MSG SEND	
108	Tamper	
107	Tamper High	
207	Tamper High Restore	
106	Tamper Low	
206	Tamper Low Restore	
208	Tamper Restore	
65061	TASK FAILURE	
65062	TASK RESTORE	
32009	Test Alarm	
32521	Test Isolate	
31753	Test Restore	
32265	Test Tamper	
65063	WORKSTATION DROPPED OFF NETWORK	

65064	WORKSTATION RESTORE	
32039	Zone 1 (onboard input) Alarm	
32551	Zone 1 (onboard input) Isolate	
31783	Zone 1 (onboard input) Restore	
32295	Zone 1 (onboard input) Tamper	
32048	Zone 10 (onboard input) Alarm	
32560	Zone 10 (onboard input) Isolate	
31792	Zone 10 (onboard input) Restore	
32304	Zone 10 (onboard input) Tamper	
32049	Zone 11 (onboard input) Alarm	
32561	Zone 11 (onboard input) Isolate	
31793	Zone 11 (onboard input) Restore	
32305	Zone 11 (onboard input) Tamper	
32050	Zone 12 (onboard input) Alarm	
32562	Zone 12 (onboard input) Isolate	
31794	Zone 12 (onboard input) Restore	
32306	Zone 12 (onboard input) Tamper	
32040	Zone 2 (onboard input) Alarm	
32552	Zone 2 (onboard input) Isolate	
31784	Zone 2 (onboard input) Restore	
32296	Zone 2 (onboard input) Tamper	
32041	Zone 3 (onboard input) Alarm	
32553	Zone 3 (onboard input) Isolate	
31785	Zone 3 (onboard input) Restore	
32297	Zone 3 (onboard input) Tamper	
32042	Zone 4 (onboard input) Alarm	
32554	Zone 4 (onboard input) Isolate	
31786	Zone 4 (onboard input) Restore	
32298	Zone 4 (onboard input) Tamper	
32043	Zone 5 (onboard input) Alarm	

32555	Zone 5 (onboard input) Isolate	
31787	Zone 5 (onboard input) Restore	
32299	Zone 5 (onboard input) Tamper	
32044	Zone 6 (onboard input) Alarm	
32556	Zone 6 (onboard input) Isolate	
31788	Zone 6 (onboard input) Restore	
32300	Zone 6 (onboard input) Tamper	
32045	Zone 7 (onboard input) Alarm	
32557	Zone 7 (onboard input) Isolate	
31789	Zone 7 (onboard input) Restore	
32301	Zone 7 (onboard input) Tamper	
32046	Zone 8 (onboard input) Alarm	
32558	Zone 8 (onboard input) Isolate	
31790	Zone 8 (onboard input) Restore	
32302	Zone 8 (onboard input) Tamper	
32047	Zone 9 (onboard input) Alarm	
32559	Zone 9 (onboard input) Isolate	
31791	Zone 9 (onboard input) Restore	
32303	Zone 9 (onboard input) Tamper	
109	ZST Fail	
209	ZST Fail Restore	

Schedule

Day	Time	Open/Close
-----	------	------------