

## Type Report

Report Date: 17/04/2013

SIA1000101 SIA Format Template

Type No	Description	Action Plan
8398	AN - Analog Restoral	Restoral, No Alarm
8402	AR-AC Restoral	Restoral, No Alarm
8403	AS - Analog Service	System Alarm
8404	AT-AC trouble	System Alarm
8513	BA-Burglary alarm	Medium Priority Alarm
8514	BB-Burglary bypass	Low Priority Alarm
8515	BC-Burglary cancel	Low Priority Alarm
8516	BD - Swinger Trouble	System Alarm
8517	BE - Swinger Trbl Restore	Restoral, No Alarm
8520	BH-Burglary A. rest.	Restoral, No Alarm
8522	BJ-Burglary T. rest.	Restoral, No Alarm
8525	BM - Burg Alarm Cross Pnt	Low Priority Alarm
8530	BR-Burglary restoral	Restoral, No Alarm
8531	BS-Burglary supervisory.	Low Priority Alarm
8532	BT-Burglary trouble	Medium Priority Alarm
8533	BU-Burglary unbyypass	Low Priority Alarm
8534	BV-Burglary Verified	Low Priority Alarm
8536	BX-Burglary test	Low Priority Alarm
8538	BZ - Missing Supervision	Low Priority Alarm
8641	CA-Automatic closing	System Alarm
8644	CD - Closing Delinquent	System Alarm
8645	CE-Closing extend	System Alarm
8646	CF-Forced closing	System Alarm
8647	CG-Close area	System Alarm
8649	CI-Fail to close	Low Priority Alarm
8650	CJ-Late close	Low Priority Alarm
8651	CK-Early close	Low Priority Alarm
8652	CL-Closing report	Closing (Set), No Alarm
8653	CM - Missing AI-Recnt Cls	System Alarm

8656	CP-Automatic closing	System Alarm
8658	CR-Recent closing	System Alarm
8659	CS-Closing switch	System Alarm
8660	CT-Late to open	Low Priority Alarm
8663	CW-Was force armed	Low Priority Alarm
8666	CZ-PPoint closing	System Alarm
8769	DA - Card Assigned	System Alarm
8770	DB - Card Deleted	System Alarm
8771	DC-Access closed	System Alarm
8772	DD-Access denied	System Alarm
8773	DE - Request To Enter	System Alarm
8774	DF-Door forced	Low Priority Alarm
8775	DG-Access granted	System Alarm
8776	DH - Door Left Open-Rstrl	Restoral, No Alarm
8778	DJ - Door Forced - Trouble	Low Priority Alarm
8779	DK-Access lockout	System Alarm
8780	DL - Door Left Open-Alarm	System Alarm
8781	DM - Door Left Open-Trbl	System Alarm
8782	DN - Door Left Open	System Alarm
8783	DO-Access open	System Alarm
8784	DP - Access Denied-Bad TM	System Alarm
8785	DQ - Access Denied-Un Arm	System Alarm
8786	DR-Door restoral	Restoral, No Alarm
8787	DS-Door station	System Alarm
8788	DT-access trouble	System Alarm
8789	DU-dealer ID	System Alarm
8790	DV - Access Denied-Un Ent	System Alarm
8791	DW - Access Denied -Intrk	System Alarm
8792	DX - Request To Exit	System Alarm
8793	DX - Door Locked	System Alarm
8794	DZ - Access Closed State	System Alarm
8897	EA-Exit Alarm	System Alarm
8901	EE-Exit error	System Alarm
8914	ER-Expansion rest.	Restoral, No Alarm
8916	ET-Expansion trouble	System Alarm

8920	EX - Extrnl Device State	System Alarm
8922	EZ - Missing Alarm-Ext ER	System Alarm
9025	FA-Fire alarm	High Priority Alarm
9026	FB-Fire bypass	Low Priority Alarm
9027	FC - Fire Cancel	Low Priority Alarm
9032	FH-Fire Alarm restore	Restoral, No Alarm
9033	FI-Firetest begin	Low Priority Alarm
9034	FJ-Fire trouble restore	Restoral, No Alarm
9035	FK-Fire test end	Low Priority Alarm
9037	FM - Fire Alarm Cross Pnt	High Priority Alarm
9042	FR-Fire restoral	Restoral, No Alarm
9043	FS-Fire supervisory	Low Priority Alarm
9044	FT-Fire trouble	High Priority Alarm
9045	FU-Fire unbypass	Low Priority Alarm
9048	FX-Fire test	Low Priority Alarm
9049	FY-Missing fire Trouble	Medium Priority Alarm
9050	FZ - Missing Fire Sprv	Medium Priority Alarm
9153	GA-Gas alarm	High Priority Alarm
9154	GB-Gas bypass	Low Priority Alarm
9160	GH-Gas A. restore	Restoral, No Alarm
9162	GJ-Gas T. restore	Restoral, No Alarm
9170	GR-Gas restoral	Restoral, No Alarm
9171	GS-Gas supervisory	Low Priority Alarm
9172	GT-Gas trouble	Medium Priority Alarm
9173	GU-Gas unbypass	Low Priority Alarm
9176	GX-Gas test gas	Low Priority Alarm
9281	HA-Hold up alam	Medium Priority Alarm
9282	HB-Hold-up bypass	Low Priority Alarm
9288	HH-Hold-up a. rest.	Restoral, No Alarm
9290	HJ-Hold-up T. rest.	Restoral, No Alarm
9298	HR-Hold-up restoral	Restoral, No Alarm
9299	HS-Hold-up supervisory	Low Priority Alarm
9300	HT-Hold-up trouble	Medium Priority Alarm
9301	HU-Hold-up unbypass	Low Priority Alarm
9409	IA - Eqpmt Fail Condition	System Alarm
9426	IR - Eqpmt Fail Restore	Restoral, No Alarm
9537	JA-User code tamper	System Alarm
9540	JD-Date changed	System Alarm
9544	JH-Holiday changed	System Alarm

9547	JK - Latchkey Alert	System Alarm
9548	JL-Log threshold	System Alarm
9551	JO-Log overflow	System Alarm
9552	JP - User On Premises	System Alarm
9554	JR-Schedule execute	System Alarm
9555	JS-Schedule change	System Alarm
9556	JT-Time changed	System Alarm
9558	JV-User code change	System Alarm
9560	JX-User code delete	System Alarm
9561	JY - User Code Added	System Alarm
9562	JZ - User Level Set	System Alarm
9665	KA-Heat alarm	Medium Priority Alarm
9666	KB-Heat bypass	Low Priority Alarm
9672	KH-Heat Alarm restore	Restoral, No Alarm
9674	KJ-heat trouble restore	Restoral, No Alarm
9682	KR-Heat restoral	Restoral, No Alarm
9683	KS-Heat supervisory	Low Priority Alarm
9684	KT-Heat trouble	Low Priority Alarm
9685	KU-Heat unbypass	Low Priority Alarm
9794	LB-Local program	System Alarm
9796	LD-Local program denied	System Alarm
9797	LE-Listen-in ended	Zone Info, No Alarm
9798	LF-Listen-in begin	Zone Info, No Alarm
9810	LR-Phone line rest.	Restoral, No Alarm
9811	LS-Local program	System Alarm
9812	LT-Phone line trouble	System Alarm
9813	LU-Local program fail	System Alarm
9816	LX-Local program ended	System Alarm
9823	L_ - Listen In + Seconds	Zone Info, No Alarm
9921	MA-Medical alarm	High Priority Alarm
9922	MB-Medical bypass	Low Priority Alarm
9928	MH-Medical alarm restore	Restoral, No Alarm
9930	MJ-Medical T. test	Low Priority Alarm
9938	MR-Medical restoral	Restoral, No Alarm
9939	MS-Medical supervisory	Low Priority Alarm
9940	MT-Medical trouble	High Priority Alarm

9941	MU-Medical unbypass	Low Priority Alarm
10049	NA-No activity	System Alarm
10051	NC - Network Condition	System Alarm
10054	NF-Forced perimeter arm	System Alarm
10060	NL-Perimeter armed	System Alarm
10066	NR - Network Restoral	Restoral, No Alarm
10067	NS - Activity Resumed	System Alarm
10068	NT - Network Failure	System Alarm
10177	OA-Automatic opening	System Alarm
10179	OC-Cancel report	System Alarm
10183	OG-Open area	System Alarm
10184	OH - Early To Opn From AL	Low Priority Alarm
10185	OI-Fail to open	Low Priority Alarm
10186	OJ-Late open	Low Priority Alarm
10187	OK-Early open	Low Priority Alarm
10188	OL - Late To Open From AL	Low Priority Alarm
10192	OP-Opening report	Opening (Unset), No Alarm
10194	OR-Disarm from alarm	System Alarm
10195	OS-Opening keyswitch	System Alarm
10196	OT-Late to close	Low Priority Alarm
10202	OZ-Point opening	System Alarm
10305	PA-Panic alarm	High Priority Alarm
10306	PB-Panic bypass	Low Priority Alarm
10312	PH-Panic alarm restore	Restoral, No Alarm
10314	PJ-Panic trouble restore	Restoral, No Alarm
10322	PR-Panic restoral	Restoral, No Alarm
10323	PS-Panic supervisory	Low Priority Alarm
10324	PT-Panic trouble	High Priority Alarm
10325	PU-Panic unbypass	Low Priority Alarm
10433	QA-Emergency alarm	High Priority Alarm
10434	QB-Emergency bypass	Low Priority Alarm
10440	QH-Emergency. A. rest.	Restoral, No Alarm
10442	QJ-Emergency. T. rest	Restoral, No Alarm
10450	QR-Emergency. Restoral	Restoral, No Alarm
10451	QS-Emergency. Supervisory	Low Priority Alarm

10452	QT-Emergency Trouble	High Priority Alarm
10453	QU-Emergency. Unbypass	Low Priority Alarm
10561	RA-Remote Programmer Called failed	System Alarm
10562	RB-Remote programmer begin	System Alarm
10563	RC-Relay close	System Alarm
10564	RD-Remote Program Denied	System Alarm
10574	RN-Remote reset	System Alarm
10575	RO-Relay open	System Alarm
10576	RP-Automatic test	System Alarm
10578	RR-Power up	System Alarm
10579	RS-Remote Program Success	System Alarm
10580	RT-Data lost	System Alarm
10581	RU-Remote Program fail	System Alarm
10584	RX-Manual test	Zone Info, No Alarm
10585	RY - Test Off Normal	System Alarm
10689	SA-Sprinkler alarm	Low Priority Alarm
10690	SB-Sprinkler. Bypass	Low Priority Alarm
10696	SH-Sprinkler. Alarm restore	Restoral, No Alarm
10698	SJ-Sprinkler. Trouble restore	Restoral, No Alarm
10706	SR-Sprinkler. Restore	Restoral, No Alarm
10707	SS-Sprinkler. supervisory.	Low Priority Alarm
10708	ST-Sprinkler. Trouble	Low Priority Alarm
10709	SU-Sprinkler. unbypass	Low Priority Alarm
10817	TA-Tamper alarm	System Alarm
10818	TB-Tamper bypass	System Alarm
10819	TC - All Points Tested	Zone Info, No Alarm
10821	TE-Test end	Zone Info, No Alarm
10824	TH - Tamper Alm Restore	Restoral, No Alarm
10826	TJ - Tamper Trbl Restore	Restoral, No Alarm
10832	TP - Walk Test Point	System Alarm
10834	TR-Tamper restoral	Restoral, No Alarm
10835	TS-Test start	System Alarm
10836	TT - Tamper Trouble	System Alarm
10837	TU-Tamper unbypass	System Alarm

10840	TX-Test Report	System Alarm
10945	UA-ntyped zone Alarm	System Alarm
10946	UB-Untyped zone bypass	System Alarm
10952	UH-Untyped Alarm restoral	Restoral, No Alarm
10954	UJ-Untyped trouble restoral	Restoral, No Alarm
10962	UR-Untyped zone restoral	Restoral, No Alarm
10963	US-Untyped zone sup.	System Alarm
10964	UT-Untyped zone Trouble	System Alarm
10965	UU-Untyped zone unbyypass	System Alarm
10968	UX-Undefined	System Alarm
10969	UY-Untyped missing Trouble	System Alarm
10970	UZ-Untyped missing Alarm	System Alarm
11081	VI-Printer paper in	System Alarm
11087	VO-Printer paper out	System Alarm
11090	VR-Printer restore	Restoral, No Alarm
11092	VT-Printer trouble	System Alarm
11096	VX-Printer test	System Alarm
11097	VY-Printer on line	Restoral, No Alarm
11098	VZ-Printer off line	System Alarm
11201	WA-Water alarm	System Alarm
11202	WB-Water bypass	System Alarm
11208	WH-Water alarm restoral	Restoral, No Alarm
11210	WJ-Water trouble restoral	Restoral, No Alarm
11218	WR-Water restoral	Restoral, No Alarm
11219	WS-Water supervisory	System Alarm
11220	WT-Water trouble	System Alarm
11221	WU-Water unbyypass	System Alarm
11329	XA - Extra AcCnt Report	System Alarm
11333	XE-Extra point	System Alarm
11334	XF-Extra RF point	System Alarm
11336	XH - RF Interference Rst	Restoral, No Alarm
11337	XI-Sensor reset	System Alarm
11338	XJ - RF Rcvr Tamper Rst	Restoral, No Alarm
11340	XL - Low RF Signal	System Alarm
11341	XM - Missing Alrm-X Point	System Alarm

11345	XQ - RF Interference	System Alarm
11346	XR-TX battery restoral	Restoral, No Alarm
11347	XS - RF Receiver Tamper	System Alarm
11348	XT-TX battery trouble	System Alarm
11351	XW-Forced point	System Alarm
11352	XX - Fail To Test	System Alarm
11457	YA - Bell Fault	System Alarm
11458	YB-Busy seconds	System Alarm
11459	YC-Communication fail	System Alarm
11460	YD-RX line card trouble	System Alarm
11461	YE-RX line card restoral	Restoral, No Alarm
11462	YF-Parameter checksum fail	System Alarm
11463	YG-Parameter changed	System Alarm
11464	YH - Bell Restored	Restoral, No Alarm
11465	YI - Overcurrent Trouble	System Alarm
11466	YJ - Overcurrent Restore	Restoral, No Alarm
11467	YK-Communication restoral	Restoral, No Alarm
11469	YM-System battery mising	System Alarm
11470	YN-Invalid report	System Alarm
11471	YO-Unknown message	System Alarm
11472	YP - Pwr Supply Trouble	System Alarm
11473	YQ-Power supply restored	Restoral, No Alarm
11474	YR-System battery restoral	Restoral, No Alarm
11475	YS-Communication trouble	System Alarm
11476	YT-System battery restoral	Restoral, No Alarm
11479	YW-Watchdog reset	System Alarm
11480	YX-Service required	System Alarm
11481	YY-Status report	System Alarm
11482	YZ-Service completed	System Alarm
11585	ZA-Freeze alarm	System Alarm
11586	ZB-Freeze bypass	System Alarm
11592	ZH-Freeze A. restore	Restoral, No Alarm
11594	ZJ-Freeze T. restore	Restoral, No Alarm
11602	ZR-Freeze restoral	Restoral, No Alarm



11603	ZS-Freeze supervisory	System Alarm
11604	ZT-Freeze trouble	System Alarm
11605	ZU-Freeze unbypass	System Alarm
65000	Receiver in error has Restored	Restoral, No Alarm
65001	Client Late to close	Low Priority Alarm
65002	No signals received from client	System Alarm
65003	Receiver Failure	System Alarm
65005	Manual Paging Signal	Zone Info, No Alarm
65006	Pager Failure	System Alarm
65007	Client Unset out of hours	Low Priority Alarm
65009	IRFast descript logged without details	System Alarm
65012		Zone Info, No Alarm
65020	Polling Restore	Restoral, No Alarm
65021	Polling Failure	System Alarm
65022	IRFast No description logged	System Alarm
65023		Zone Info, No Alarm
65024		Zone Info, No Alarm
65025		Zone Info, No Alarm
65026	Change of Logs	Zone Info, No Alarm
65027	Successful send	Zone Info, No Alarm
65028	Alarm no restoral received	System Alarm
65029	Bad check sum in signal	System Alarm
65030	Comm port error	System Alarm
65031	Bad caller ID	System Alarm
65032	Bad unrecognised data	System Alarm
65046	Start of listen in	Zone Info, No Alarm
65047	End of listen in	Zone Info, No Alarm
65050	Multi-knock	Zone Info, No Alarm
65051	Late to open	Low Priority Alarm
65052	Early to close	Low Priority Alarm
65053	Email error	System Alarm
65054	Poll signal	Zone Info, No Alarm
65055	Receiver error message	System Alarm
65056	Attend report	Zone Info, No Alarm
65057	Publishing failed	System Alarm
65058	Publishing restored	Restoral, No Alarm
65059	Attend report complete	Zone Info, No Alarm
65061	Task dropped off network	System Alarm
65062	Task restored	Restoral, No Alarm
65063	Slave dropped off network	System Alarm
65064	Slave restored	Restoral, No Alarm
65065	Archive of current log was successful	Zone Info, No Alarm

65066	Archive of current log has failed	System Alarm
65067	Archive clean was successful	Zone Info, No Alarm
65068	Archive clean has failed	System Alarm
65069	WWW Archive was successful	Zone Info, No Alarm
65070	WWW Archive has failed	System Alarm
65071	Automatic Data Backup was successful	Zone Info, No Alarm
65072	Automatic Data Backup has failed	System Alarm