

# Type Report

Report Date: 11/12/2015

SIA1000101 SIA Format Template

Type No	Description	Action Plan
8398	AN - Analog Restoral	Restoral, No Alarm
8402	AR-AC Restoral	Restoral, No Alarm
8403	AS - Analog Service	System Alarm
8404	AT-AC trouble	System Alarm
8513	BA-Burglary alarm	General Alarm
8514	BB-Burglary bypass	System Alert
8515	BC-Burglary cancel	System Alert
8516	BD - Swinger Trouble	System Alarm
8517	BE - Swinger Trbl Restore	Restoral, No Alarm
8520	BH-Burglary A. rest.	Restoral, No Alarm
8522	BJ-Burglary T. rest.	Restoral, No Alarm
8525	BM - Burg Alarm Cross Pnt	System Alert
8530	BR-Burglary restoral	Restoral, No Alarm
8531	BS-Burglary supervisory.	System Alert
8532	BT-Burglary trouble	General Alarm
8533	BU-Burglary unbypass	System Alert
8534	BV-Burglary Verified	System Alert
8536	BX-Burglary test	System Alert
8538	BZ - Missing Supervision	System Alert
8641	CA-Automatic closing	System Alarm
8644	CD - Closing Delinquent	System Alarm
8645	CE-Closing extend	System Alarm
8646	CF-Forced closing	System Alarm
8647	CG-Close area	System Alarm
8649	CI-Fail to close	System Alert
8650	CJ-Late close	System Alert
8651	CK-Early close	System Alert
8652	CL-Closing report	Closing (Set), No Alarm
8653	CM - Missing AI-Recnt Cls	System Alarm

8656	CP-Automatic closing	System Alarm
8658	CR-Recent closing	System Alarm
8659	CS-Closing switch	System Alarm
8660	CT-Late to open	System Alert
8663	CW-Was force armed	System Alert
8666	CZ-PPoint closing	System Alarm
8769	DA - Card Assigned	System Alarm
8770	DB - Card Deleted	System Alarm
8771	DC-Access closed	System Alarm
8772	DD-Access denied	System Alarm
8773	DE - Request To Enter	System Alarm
8774	DF-Door forced	System Alert
8775	DG-Access granted	System Alarm
8776	DH - Door Left Open-Rstrl	Restoral, No Alarm
8778	DJ - Door Forced - Trouble	System Alert
8779	DK-Access lockout	System Alarm
8780	DL - Door Left Open-Alarm	System Alarm
8781	DM - Door Left Open-Trbl	System Alarm
8782	DN - Door Left Open	System Alarm
8783	DO-Access open	System Alarm
8784	DP - Access Denied-Bad TM	System Alarm
8785	DQ - Access Denied-Un Arm	System Alarm
8786	DR-Door restoral	Restoral, No Alarm
8787	DS-Door station	System Alarm
8788	DT-access trouble	System Alarm
8789	DU-dealer ID	System Alarm
8790	DV - Access Denied-Un Ent	System Alarm
8791	DW - Access Denied -Intrlk	System Alarm
8792	DX - Request To Exit	System Alarm
8793	DX - Door Locked	System Alarm
8794	DZ - Access Closed State	System Alarm
8897	EA-Exit Alarm	System Alarm
8901	EE-Exit error	System Alarm
8914	ER-Expansion rest.	Restoral, No Alarm
8916	ET-Expansion trouble	System Alarm

8920	EX - Extrnl Device State	System Alarm
8922	EZ - Missing Alarm-Ext ER	System Alarm
9025	FA-Fire alarm	Intruder Alarm
9026	FB-Fire bypass	System Alert
9027	FC - Fire Cancel	System Alert
9032	FH-Fire Alarm restore	Restoral, No Alarm
9033	FI-Firetest begin	System Alert
9034	FJ-Fire trouble restore	Restoral, No Alarm
9035	FK-Fire test end	System Alert
9037	FM - Fire Alarm Cross Pnt	Intruder Alarm
9042	FR-Fire restoral	Restoral, No Alarm
9043	FS-Fire supervisory	System Alert
9044	FT-Fire trouble	Intruder Alarm
9045	FU-Fire unbypass	System Alert
9048	FX-Fire test	System Alert
9049	FY-Missing fire Trouble	General Alarm
9050	FZ - Missing Fire Sprv	General Alarm
9153	GA-Gas alarm	Intruder Alarm
9154	GB-Gas bypass	System Alert
9160	GH-Gas A. restore	Restoral, No Alarm
9162	GJ-Gas T. restore	Restoral, No Alarm
9170	GR-Gas restoral	Restoral, No Alarm
9171	GS-Gas supervisory	System Alert
9172	GT-Gas trouble	General Alarm
9173	GU-Gas unbypass	System Alert
9176	GX-Gas test gas	System Alert
9281	HA-Hold up alam	General Alarm
9282	HB-Hold-up bypass	System Alert
9288	HH-Hold-up a. rest.	Restoral, No Alarm
9290	HJ-Hold-up T. rest.	Restoral, No Alarm
9298	HR-Hold-up restoral	Restoral, No Alarm
9299	HS-Hold-up supervisory	System Alert
9300	HT-Hold-up trouble	General Alarm
9301	HU-Hold-up unbypass	System Alert
9409	IA - Eqpmt Fail Condition	System Alarm
9426	IR - Eqpmt Fail Restore	Restoral, No Alarm
9537	JA-User code tamper	System Alarm
9540	JD-Date changed	System Alarm
9544	JH-Holiday changed	System Alarm

9547	JK - Latchkey Alert	System Alarm
9548	JL-Log threshold	System Alarm
9551	JO-Log overflow	System Alarm
9552	JP - User On Premises	System Alarm
9554	JR-Schedule execute	System Alarm
9555	JS-Schedule change	System Alarm
9556	JT-Time changed	System Alarm
9558	JV-User code change	System Alarm
9560	JX-User code delete	System Alarm
9561	JY - User Code Added	System Alarm
9562	JZ - User Level Set	System Alarm
9665	KA-Heat alarm	General Alarm
9666	KB-Heat bypass	System Alert
9672	KH-Heat Alarm restore	Restoral, No Alarm
9674	KJ-heat trouble restore	Restoral, No Alarm
9682	KR-Heat restoral	Restoral, No Alarm
9683	KS-Heat supervisory	System Alert
9684	KT-Heat trouble	System Alert
9685	KU-Heat unbypass	System Alert
9794	LB-Local program	System Alarm
9796	LD-Local program denied	System Alarm
9797	LE-Listen-in ended	Zone Info, No Alarm
9798	LF-Listen-in begin	Zone Info, No Alarm
9810	LR-Phone line rest.	Restoral, No Alarm
9811	LS-Local program	System Alarm
9812	LT-Phone line trouble	System Alarm
9813	LU-Local program fail	System Alarm
9816	LX-Local program ended	System Alarm
9823	L_ - Listen In + Seconds	Zone Info, No Alarm
9921	MA-Medical alarm	Intruder Alarm
9922	MB-Medical bypass	System Alert
9928	MH-Medical alarm restore	Restoral, No Alarm
9930	MJ-Medical T. test	System Alert
9938	MR-Medical restoral	Restoral, No Alarm
9939	MS-Medical supervisory	System Alert
9940	MT-Medical trouble	Intruder Alarm

9941	MU-Medical unbypass	System Alert
10049	NA-No activity	System Alarm
10051	NC - Network Condition	System Alarm
10054	NF-Forced perimeter arm	System Alarm
10060	NL-Perimeter armed	System Alarm
10066	NR - Network Restoral	Restoral, No Alarm
10067	NS - Activity Resumed	System Alarm
10068	NT - Network Failure	System Alarm
10177	OA-Automatic opening	System Alarm
10179	OC-Cancel report	System Alarm
10183	OG-Open area	System Alarm
10184	OH - Early To Opn From AL	System Alert
10185	OI-Fail to open	System Alert
10186	OJ-Late open	System Alert
10187	OK-Early open	System Alert
10188	OL - Late To Open From AL	System Alert
10192	OP-Opening report	Opening (Unset), No Alarm
10194	OR-Disarm from alarm	System Alarm
10195	OS-Opening keyswitch	System Alarm
10196	OT-Late to close	System Alert
10202	OZ-Point opening	System Alarm
10305	PA-Panic alarm	Intruder Alarm
10306	PB-Panic bypass	System Alert
10312	PH-Panic alarm restore	Restoral, No Alarm
10314	PJ-Panic trouble restore	Restoral, No Alarm
10322	PR-Panic restoral	Restoral, No Alarm
10323	PS-Panic supervisory	System Alert
10324	PT-Panic trouble	Intruder Alarm
10325	PU-Panic unbypass	System Alert
10433	QA-Emergency alarm	Intruder Alarm
10434	QB-Emergency bypass	System Alert
10440	QH-Emergency. A. rest.	Restoral, No Alarm
10442	QJ-Emergency. T. rest	Restoral, No Alarm
10450	QR-Emergency. Restoral	Restoral, No Alarm
10451	QS-Emergency. Supervisory	System Alert

10452	QT-Emergency Trouble	Intruder Alarm
10453	QU-Emergency. Unbypass	System Alert
10561	RA-Remote Programmer Called failed	System Alarm
10562	RB-Remote programmer begin	System Alarm
10563	RC-Relay close	System Alarm
10564	RD-Remote Program Denied	System Alarm
10574	RN-Remote reset	System Alarm
10575	RO-Relay open	System Alarm
10576	RP-Automatic test	System Alarm
10578	RR-Power up	System Alarm
10579	RS-Remote Program Success	System Alarm
10580	RT-Data lost	System Alarm
10581	RU-Remote Program fail	System Alarm
10584	RX-Manual test	Zone Info, No Alarm
10585	RY - Test Off Normal	System Alarm
10689	SA-Sprinkler alarm	System Alert
10690	SB-Sprinkler. Bypass	System Alert
10696	SH-Sprinkler. Alarm restore	Restoral, No Alarm
10698	SJ-Sprinkler. Trouble restore	Restoral, No Alarm
10706	SR-Sprinkler. Restore	Restoral, No Alarm
10707	SS-Sprinkler. supervisory.	System Alert
10708	ST-Sprinkler. Trouble	System Alert
10709	SU-Sprinkler. unbypass	System Alert
10817	TA-Tamper alarm	System Alarm
10818	TB-Tamper bypass	System Alarm
10819	TC - All Points Tested	Zone Info, No Alarm
10821	TE-Test end	Zone Info, No Alarm
10824	TH - Tamper Alm Restore	Restoral, No Alarm
10826	TJ - Tamper Trbl Restore	Restoral, No Alarm
10832	TP - Walk Test Point	System Alarm
10834	TR-Tamper restoral	Restoral, No Alarm
10835	TS-Test start	Test Report
10836	TT - Tamper Trouble	System Alarm
10837	TU-Tamper unbypass	System Alarm

10840	TX-Test Report	Test Report
10945	UA-ntyped zone Alarm	System Alarm
10946	UB-Untyped zone bypass	System Alarm
10952	UH-Untyped Alarm restoral	Restoral, No Alarm
10954	UJ-Untyped trouble restoral	Restoral, No Alarm
10962	UR-Untyped zone restoral	Restoral, No Alarm
10963	US-Untyped zone sup.	System Alarm
10964	UT-Untyped zone Trouble	System Alarm
10965	UU-Untyped zone unbyypass	System Alarm
10968	UX-Undefined	System Alarm
10969	UY-Untyped missing Trouble	System Alarm
10970	UZ-Untyped missing Alarm	System Alarm
11081	VI-Printer paper in	System Alarm
11087	VO-Printer paper out	System Alarm
11090	VR-Printer restore	Restoral, No Alarm
11092	VT-Printer trouble	System Alarm
11096	VX-Printer test	System Alarm
11097	VY-Printer on line	Restoral, No Alarm
11098	VZ-Printer off line	System Alarm
11201	WA-Water alarm	System Alarm
11202	WB-Water bypass	System Alarm
11208	WH-Water alarm restoral	Restoral, No Alarm
11210	WJ-Water trouble restoral	Restoral, No Alarm
11218	WR-Water restoral	Restoral, No Alarm
11219	WS-Water supervisory	System Alarm
11220	WT-Water trouble	System Alarm
11221	WU-Water unbyypass	System Alarm
11329	XA - Extra AcCnt Report	System Alarm
11333	XE-Extra point	System Alarm
11334	XF-Extra RF point	System Alarm
11336	XH - RF Interference Rst	Restoral, No Alarm
11337	XI-Sensor reset	System Alarm
11338	XJ - RF Rcvr Tamper Rst	Restoral, No Alarm
11340	XL - Low RF Signal	System Alarm
11341	XM - Missing Alrm-X Point	System Alarm

11345	XQ - RF Interference	System Alarm
11346	XR-TX battery restoral	Restoral, No Alarm
11347	XS - RF Receiver Tamper	System Alarm
11348	XT-TX battery trouble	System Alarm
11351	XW-Forced point	System Alarm
11352	XX - Fail To Test	System Alarm
11457	YA - Bell Fault	System Alarm
11458	YB-Busy seconds	System Alarm
11459	YC-Communication fail	System Alarm
11460	YD-RX line card trouble	System Alarm
11461	YE-RX line card restoral	Restoral, No Alarm
11462	YF-Parameter checksum fail	System Alarm
11463	YG-Parameter changed	System Alarm
11464	YH - Bell Restored	Restoral, No Alarm
11465	YI - Overcurrent Trouble	System Alarm
11466	YJ - Overcurrent Restore	Restoral, No Alarm
11467	YK-Communication restoral	Restoral, No Alarm
11469	YM-System battery mising	System Alarm
11470	YN-Invalid report	System Alarm
11471	YO-Unknown message	System Alarm
11472	YP - Pwr Supply Trouble	System Alarm
11473	YQ-Power supply restored	Restoral, No Alarm
11474	YR-System battery restoral	Restoral, No Alarm
11475	YS-Communication trouble	System Alarm
11476	YT-System battery restoral	Restoral, No Alarm
11479	YW-Watchdog reset	System Alarm
11480	YX-Service required	System Alarm
11481	YY-Status report	System Alarm
11482	YZ-Service completed	System Alarm
11585	ZA-Freeze alarm	System Alarm
11586	ZB-Freeze bypass	System Alarm
11592	ZH-Freeze A. restore	Restoral, No Alarm
11594	ZJ-Freeze T. restore	Restoral, No Alarm
11602	ZR-Freeze restoral	Restoral, No Alarm



11603	ZS-Freeze supervisory	System Alarm
11604	ZT-Freeze trouble	System Alarm
11605	ZU-Freeze unbypass	System Alarm