

Type Report

Report Date: 11/12/2015

INTR000101 IR Fast Integriti

Type No	Description	Action Plan
1	Close	Closing (Set), No Alarm
2	Open	Opening (Unset), No Alarm
101	Alarm	General Alarm
102	Mask	General Alarm
103	Orient	General Alarm
104	Fault	General Alarm
105	Range	General Alarm
106	Tamper Low	General Alarm
107	Tamper High	General Alarm
108	Tamper	General Alarm
109	ZST Fail	General Alarm
110	Low Battery	General Alarm
111	Crypt Fail	General Alarm
112	Poll Fail	General Alarm
113	State 12	General Alarm
114	Soaking	General Alarm
115	Soak Fail	General Alarm
116	Isolate	General Alarm
201	Alarm Restore	Restoral, No Alarm
202	Mask Restore	Restoral, No Alarm
203	Orient Restore	Restoral, No Alarm
204	Fault Restore	Restoral, No Alarm
205	Range Restore	Restoral, No Alarm
206	Tamper Low Restore	Restoral, No Alarm
207	Tamper High Restore	Restoral, No Alarm
208	Tamper Restore	Restoral, No Alarm
209	ZST Fail Restore	Restoral, No Alarm
210	Low Battery Restore	Restoral, No Alarm
211	Crypt Fail Restore	Restoral, No Alarm
212	Poll Restore	Restoral, No Alarm
213	State 12 Restore	Restoral, No Alarm
214	Soaking Restore	Restoral, No Alarm
215	Soak Restore	Restoral, No Alarm
216	Isolate Restore	Restoral, No Alarm
30723	Restore Loss of Polling	Restoral, No Alarm
30724	Restore Message Quarantined	Restoral, No Alarm
30725	Restore Alarm out of Sequence	Restoral, No Alarm

30726	Restore Panel Unenrolled	Restoral, No Alarm
30727	Restore Panel serial number has changed	Restoral, No Alarm
30728	Restore Invalid message format - Contact	Restoral, No Alarm
30729	Restore Invalid message format - IRFast	Restoral, No Alarm
30730	Restore Installer access timer has start	Restoral, No Alarm
30731	Restore Installer access timer has stopp	Restoral, No Alarm
30732	Restore Ethernet path warning	Restoral, No Alarm
30733	Restore GPRS 1 path warning	Restoral, No Alarm
30734	Restore GPRS 2 path warning	Restoral, No Alarm
30735	Restore PSTN path warning	Restoral, No Alarm
30736	Restore Repeated loss of polling	Restoral, No Alarm
30737	Restore Alternate path warning	Restoral, No Alarm
30738	Restore Repeated Ethernet Path Warning	Restoral, No Alarm
30739	Restore Repeated GPRS 1 Path Warning	Restoral, No Alarm
30740	Restore Repeated GPRS 2 Path Warning	Restoral, No Alarm
30741	Restore Repeated Dialup ISP Path Warning	Restoral, No Alarm
30743	Restore STU Changed path to Ethernet	Restoral, No Alarm
30744	Restore STU changed path to GPRS 1	Restoral, No Alarm
30745	Restore STU changed path to GPRS 2	Restoral, No Alarm
30746	Restore STU changed path to Dial-up ISP	Restoral, No Alarm
30747	Restore STU Service Required	Restoral, No Alarm
30749	Restore Dial-up ISP path warning	Restoral, No Alarm
30979	Alarm Loss of Polling	System Alarm
30980	Alarm Message Quarantined	System Alarm
30981	Alarm Alarm out of Sequence	System Alarm
30982	Alarm Panel Unenrolled	System Alarm
30983	Alarm Panel serial number has changed	System Alarm
30984	Alarm Invalid message format - ContactID	System Alarm
30985	Alarm Invalid message format - IRFast	System Alarm
30986	Alarm Installer access timer has started	System Alarm
30987	Alarm Installer access timer has stopped	System Alarm
30988	Alarm Ethernet path warning	System Alarm
30989	Alarm GPRS 1 path warning	System Alarm
30990	Alarm GPRS 2 path warning	System Alarm
30991	Alarm PSTN path warning	System Alarm
30992	Alarm Repeated loss of polling	System Alarm
30993	Alarm Alternate path warning	System Alarm

30994	Alarm Repeated Ethernet Path Warning	System Alarm
30995	Alarm Repeated GPRS 1 Path Warning	System Alarm
30996	Alarm Repeated GPRS 2 Path Warning	System Alarm
30997	Restore Repeated Dialup ISP Path Warning	System Alarm
30999	Alarm STU Changed path to Ethernet	System Alarm
31000	Alarm STU changed path to GPRS 1	System Alarm
31001	Alarm STU changed path to GPRS 2	System Alarm
31002	Alarm STU changed path to Dial-up ISP	System Alarm
31003	Alarm STU Service Required	System Alarm
31005	Alarm Dial-up ISP path warning	System Alarm
31747	Reset Restore	System Alarm
31748	Programming Change Restore	System Alarm
31749	Panic Restore	System Alarm
31750	Low Battery Restore	System Alarm
31751	Battery Test Restore	System Alarm
31752	Power Restore	System Alarm
31753	Test Restore	System Alarm
31754	Lost alarms Restore	System Alarm
31755	Armed Restore	System Alarm
31756	Panel Fail Restore	System Alarm
31757	RF Hardware Restore	System Alarm
31758	RF Registration Restore	System Alarm
31759	RF Low Signal Strength Restore	System Alarm
31760	RF Problems Restore	System Alarm
31761	GPRS Registration Restore	System Alarm
31762	PSTN Line Volts Low Restore	System Alarm
31763	PSTN Link Restore	System Alarm
31764	PSTN Problems Restore	System Alarm
31765	Network Hardware Restore	System Alarm
31766	Network Online Restore	System Alarm
31767	Network Problems Restore	System Alarm
31768	External Hardware Restore	System Alarm
31769	Alarm Panel Serial Connection Problems R	System Alarm
31770	Alarm Panel Serial Connection Failed Res	System Alarm
31771	Alarm Panel Substitution Alarm Restore	System Alarm
31783	Zone 1 (onboard input) Restore	System Alarm
31784	Zone 2 (onboard input) Restore	System Alarm
31785	Zone 3 (onboard input) Restore	System Alarm
31786	Zone 4 (onboard input) Restore	System Alarm
31787	Zone 5 (onboard input) Restore	System Alarm
31788	Zone 6 (onboard input) Restore	System Alarm

31789	Zone 7 (onboard input) Restore	System Alarm
31790	Zone 8 (onboard input) Restore	System Alarm
31791	Zone 9 (onboard input) Restore	System Alarm
31792	Zone 10 (onboard input) Restore	System Alarm
31793	Zone 11 (onboard input) Restore	System Alarm
31794	Zone 12 (onboard input) Restore	System Alarm
32003	Reset Alarm	System Alarm
32004	Programming Change Alarm	System Alarm
32005	Panic Alarm	System Alarm
32006	Low Battery Alarm	System Alarm
32007	Battery Test Alarm	System Alarm
32008	Power Alarm	System Alarm
32009	Test Alarm	System Alarm
32010	Lost alarms Alarm	System Alarm
32011	Armed Alarm	System Alarm
32012	Panel Fail Alarm	System Alarm
32013	RF Hardware Alarm	System Alarm
32014	RF Registration Alarm	System Alarm
32015	RF Low Signal Strength Alarm	System Alarm
32016	RF Problems Alarm	System Alarm
32017	GPRS Registration Alarm	System Alarm
32018	PSTN Line Volts Low Alarm	System Alarm
32019	PSTN Link Alarm	System Alarm
32020	PSTN Problems Alarm	System Alarm
32021	Network Hardware Alarm	System Alarm
32022	Network Online Alarm	System Alarm
32023	Network Problems Alarm	System Alarm
32024	External Hardware Alarm	System Alarm
32025	Alarm Panel Serial Connection Problems A	System Alarm
32026	Alarm Panel Serial Connection Failed Ala	System Alarm
32027	Alarm Panel Substitution Alarm Alarm	System Alarm
32039	Zone 1 (onboard input) Alarm	System Alarm
32040	Zone 2 (onboard input) Alarm	System Alarm
32041	Zone 3 (onboard input) Alarm	System Alarm
32042	Zone 4 (onboard input) Alarm	System Alarm
32043	Zone 5 (onboard input) Alarm	System Alarm
32044	Zone 6 (onboard input) Alarm	System Alarm
32045	Zone 7 (onboard input) Alarm	System Alarm
32046	Zone 8 (onboard input) Alarm	System Alarm
32047	Zone 9 (onboard input) Alarm	System Alarm
32048	Zone 10 (onboard input) Alarm	System Alarm
32049	Zone 11 (onboard input) Alarm	System Alarm
32050	Zone 12 (onboard input) Alarm	System Alarm
32259	Reset Tamper	System Alarm

32260	Programming Change Tamper	System Alarm
32261	Panic Tamper	System Alarm
32262	Low Battery Tamper	System Alarm
32263	Battery Test Tamper	System Alarm
32264	Power Tamper	System Alarm
32265	Test Tamper	System Alarm
32266	Lost alarms Tamper	System Alarm
32267	Armed Tamper	System Alarm
32268	Panel Fail Tamper	System Alarm
32269	RF Hardware Tamper	System Alarm
32270	RF Registration Tamper	System Alarm
32271	RF Low Signal Strength Tamper	System Alarm
32272	RF Problems Tamper	System Alarm
32273	GPRS Registration Tamper	System Alarm
32274	PSTN Line Volts Low Tamper	System Alarm
32275	PSTN Link Tamper	System Alarm
32276	PSTN Problems Tamper	System Alarm
32277	Network Hardware Tamper	System Alarm
32278	Network Online Tamper	System Alarm
32279	Network Problems Tamper	System Alarm
32280	External Hardware Tamper	System Alarm
32281	Alarm Panel Serial Connection Problems T	System Alarm
32282	Alarm Panel Serial Connection Failed Tam	System Alarm
32283	Alarm Panel Substitution Alarm Tamper	System Alarm
32295	Zone 1 (onboard input) Tamper	System Alarm
32296	Zone 2 (onboard input) Tamper	System Alarm
32297	Zone 3 (onboard input) Tamper	System Alarm
32298	Zone 4 (onboard input) Tamper	System Alarm
32299	Zone 5 (onboard input) Tamper	System Alarm
32300	Zone 6 (onboard input) Tamper	System Alarm
32301	Zone 7 (onboard input) Tamper	System Alarm
32302	Zone 8 (onboard input) Tamper	System Alarm
32303	Zone 9 (onboard input) Tamper	System Alarm
32304	Zone 10 (onboard input) Tamper	System Alarm
32305	Zone 11 (onboard input) Tamper	System Alarm
32306	Zone 12 (onboard input) Tamper	System Alarm
32515	Reset Isolate	System Alarm
32516	Programming Change Isolate	System Alarm
32517	Panic Isolate	System Alarm
32518	Low Battery Isolate	System Alarm
32519	Battery Test Isolate	System Alarm
32520	Power Isolate	System Alarm
32521	Test Isolate	System Alarm
32522	Lost alarms Isolate	System Alarm
32523	Armed Isolate	System Alarm
32524	Panel Fail Isolate	System Alarm

32525	RF Hardware Isolate	System Alarm
32526	RF Registration Isolate	System Alarm
32527	RF Low Signal Strength Isolate	System Alarm
32528	RF Problems Isolate	System Alarm
32529	GPRS Registration Isolate	System Alarm
32530	PSTN Line Volts Low Isolate	System Alarm
32531	PSTN Link Isolate	System Alarm
32532	PSTN Problems Isolate	System Alarm
32533	Network Hardware Isolate	System Alarm
32534	Network Online Isolate	System Alarm
32535	Network Problems Isolate	System Alarm
32536	External Hardware Isolate	System Alarm
32537	Alarm Panel Serial Connection Problems I	System Alarm
32538	Alarm Panel Serial Connection Failed Iso	System Alarm
32539	Alarm Panel Substitution Alarm Isolate	System Alarm
32551	Zone 1 (onboard input) Isolate	System Alarm
32552	Zone 2 (onboard input) Isolate	System Alarm
32553	Zone 3 (onboard input) Isolate	System Alarm
32554	Zone 4 (onboard input) Isolate	System Alarm
32555	Zone 5 (onboard input) Isolate	System Alarm
32556	Zone 6 (onboard input) Isolate	System Alarm
32557	Zone 7 (onboard input) Isolate	System Alarm
32558	Zone 8 (onboard input) Isolate	System Alarm
32559	Zone 9 (onboard input) Isolate	System Alarm
32560	Zone 10 (onboard input) Isolate	System Alarm
32561	Zone 11 (onboard input) Isolate	System Alarm
32562	Zone 12 (onboard input) Isolate	System Alarm